



15/17" MODEL


Side View



Front View




Mounting Plate




19" MODEL


Side View



Front View



Mounting Plate



© 2026



Hope Industrial Systems, Inc.

Toll Free: (877) 762-9790 • International: +1 (678) 762-9790  
UK: +44 (0) 20 7193-2618 • E-mail: support@HopeIndustrial.com

Part Number: YB and YK series

Date: 2022.08.26

NOTES: 1) 2" screw nuts and washers are provided as alternate for mounting.


2) Yoke will rotate +/- 320° from front center.

Revision:


Page 2 of 5

19.5" MODEL


Side View



Front View



Mounting Plate



© 2026



Hope Industrial Systems, Inc.

Toll Free: (877) 762-9790 • International: +1 (678) 762-9790  
UK: +44 (0) 20 7193-2618 • E-mail: support@HopeIndustrial.com

Part Number: YB and YK series

Date: 2022.08.26

NOTES: 1) 2" screw nuts and washers are provided as alternate for mounting.


2) Yoke will rotate +/- 320° from front center.

Revision:


Page 3 of 5

22" MODEL


Side View



Front View



Mounting Plate



© 2026



Hope Industrial Systems, Inc.

Toll Free: (877) 762-9790 • International: +1 (678) 762-9790  
UK: +44 (0) 20 7193-2618 • E-mail: support@HopeIndustrial.com

Part Number: YB and YK series

Date: 2022.08.26

NOTES: 1) 2" screw nuts and washers are provided as alternate for mounting.


2) Yoke will rotate +/- 320° from front center.

Revision:


Page 4 of 5

23.8" MODEL


Side View



Front View



Mounting Plate



© 2026



Hope Industrial Systems, Inc.

Toll Free: (877) 762-9790 • International: +1 (678) 762-9790  
UK: +44 (0) 20 7193-2618 • E-mail: support@HopeIndustrial.com

Part Number: YB and YK series

Date: 2022.08.26

NOTES: 1) 2" screw nuts and washers are provided as alternate for mounting.

2) Yoke will rotate +/- 320° from front center.

Revision:

Page 5 of 5